




TLV-1081XT

SERVICE MANUAL

COLOR TELEVISION/VIDEO CASSETTE RECORDER



**ORIGINAL
MFR'S VERSION B**

SERVICING NOTICES ON CHECKING

1. KEEP THE NOTICES

As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

2. AVOID AN ELECTRIC SHOCK

There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.

3. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a \triangle mark, the designated parts must be used.

4. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

5. TAKE CARE TO DEAL WITH THE CATHODE-RAY TUBE

In the condition that an explosion-proof cathode-ray tube is set in this equipment, safety is secured against implosion. However, when removing it or serving from backward, it is dangerous to give a shock. Take enough care to deal with it.

6. AVOID AN X-RAY

Safety is secured against an X-ray by considering about the cathode-ray tube and the high voltage peripheral circuit, etc.

Therefore, when repairing the high voltage peripheral circuit, use the designated parts and make sure not modify the circuit.

Repairing except indicates causes rising of high voltage, and it emits an X-ray from the cathode-ray tube.

7. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

(INSULATION CHECK PROCEDURE)

1. Unplug the plug from the AC outlet.
2. Remove the antenna terminal on TV and turn on the TV.
3. Insulation resistance between the cord plug terminals and the eternal exposure metal
[Note 2] should be more than 1M ohm by using the 500V insulation resistance meter
[Note1] .
4. If the insulation resistance is less than 1M ohm, the inspection repair should be required.

[Note 1]

If you have not the 500V insulation resistance meter, use a Tester.

[Note 2]

External exposure metal: Antenna terminal
Earphone jack

HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

1. MODEL NUMBER and VERSION LETTER

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

CONTENTS

SERVICING NOTICES ON CHECKING	A1-1
HOW TO ORDER PARTS	A1-1
CONTENTS	A2-1
GENERAL SPECIFICATIONS	A3-1~A3-6
DISASSEMBLY INSTRUCTIONS	
1. REMOVAL OF MECHANICAL PARTS AND P. C. BOARDS	B1-1, B1-2
2. REMOVAL OF DECK PARTS	B2-1~B2-5
3. REMOVAL OF ANODE CAP	B3-1, B3-2
KEY TO ABBREVIATIONS	C1-1, C1-2
SERVICE MODE LIST	C2-1
PREVENTIVE CHECKS AND SERVICE INTERVALS	C3-1, C3-2
NOTE FOR THE REPLACING OF MEMORY IC	C4-1
SERVICING FIXTURES AND TOOLS	C5-1, C5-2
MECHANICAL ADJUSTMENTS	D1-1~D1-4
ELECTRICAL ADJUSTMENTS	D2-1~D2-6
BLOCK DIAGRAMS	
TV	E-1, E-2
Y/C/AUDIO/HEAD AMP/21PIN/IN/OUT	E-3, E-4
MICON/POWER/OPERATION/DECK	E-5, E-6
T' TEXT	E-7, E-8
PRINTED CIRCUIT BOARDS	
MAIN/CRT	F-1, F-2
OPERATION/DECK	F-3, F-4
SYSCON	F-5~F-8
SCHEMATIC DIAGRAMS	
Y/C/AUDIO/HEAD AMP	G-1, G-2
MICON	G-3, G-4
POWER	G-5, G-6
21PIN/IN/OUT	G-7, G-8
CHROMA/IF	G-9, G-10
SOUND AMP	G-11, G-12
T' TEXT	G-13, G-14
TV POWER	G-15, G-16
DEFLECTION	G-17, G-18
CRT	G-19, G-20
OPERATION	G-21, G-22
DECK	G-23, G-24
INTERCONNECTION DIAGRAM	G-25, G-26
WAVEFORMS	H-1~H-3
MECHANICAL EXPLODED VIEWS	I-1, I-2
CHASSIS EXPLODED VIEWS	I-3, I-4
MECHANICAL REPLACEMENT PARTS LIST	J1-1
CHASSIS REPLACEMENT PARTS LIST	J2-1
ELECTRICAL REPLACEMENT PARTS LIST	J3-1~J3-3

GENERAL SPECIFICATIONS

G-1. Outline of the Product

10 inch(228.6 mmV):Measured diagonally

Color CRT 76 degree deflection

1-Speed 1/2" Video Cassette Recorder

VHS
 VHS-C

Recorder/Player
 Player

G-2. VCR Format

VHS Standard

NTSC PAL SECAM PAL-M PAL-N
 VHS Hi-Fi Audio System

G-3. Video Recording System

Luminance Component

:Rotary, slant azimuth two head helical scan system

Chrominance Component

:FM recording

:Low frequency converted direct recording

G-4. Broadcasting System

: CCIR System B/G

G-5. Color System

NTSC PAL SECAM or Monochrome signal

G-6. NTSC Playback(PAL 60Hz)

Yes No

G-7. MESECAM

Yes No

G-8. Cassette Tape

VHS type video cassette tape Width 12.65mm (1/2 Inch)

VHS-C type video cassette tape Width 12.65mm (1/2 Inch)

G-9. Tape Speed

NTSC or PAL-M

SP 33.35 mm/sec
 LP 16.67 mm/sec
 SLP 11.12 mm/sec

PAL or SECAM

SP 23.39 mm/sec
 LP 11.69 mm/sec

G-10. Recording/Playback Time

NTSC or PAL-M(NTSC Playback Only)

at SP Mode Max. 210 min. (with T-210 cassette)
 at LP Mode Max. 420 min. (with T-210 cassette)
 at SLP Mode Max. 630 min. (with T-210 cassette)

PAL or SECAM

at SP Mode Max. 300 min. (with E-300 cassette)
 at LP Mode Max. 600 min. (with E-300 cassette)

G-11. Rewind/Fast Forward Time(Approx.)

AC: FF :2'15" / Rew :1'48"

(T-120 cassette E-180 cassette)

FF :3'40" / Rew :2'50"

(T-120 cassette E-180 cassette)

DC: FF :3'40" / Rew :2'50"

(T-120 cassette E-180 cassette)

G-12. Search Speed

SP 5 and 7 Times(PAL)
 SP 3 and 5 Times(NTSC)
 SLP _____ Times

G-13. Slow Speed

SP 1/10 Times
 LP _____ Times
 SLP _____ Times

G-14. Frame Advance

SP 1/10 Times
 LP _____ Times
 SLP _____ Times

GENERAL SPECIFICATIONS

G-15.Antenna Input Impedance

VHF/UHF 75 ohm unbalanced

G-16.Tuner and Receiving channel

1Tuner System

2Tuner System

Tuner : Contactless Electric tuner

<input type="checkbox"/> Oscar(W/O HYPER)	<input checked="" type="checkbox"/> Oscar(W/ HYPER)	<input type="checkbox"/> France CATV)	<input type="checkbox"/> Others
channel coverage			
(SECAM)	<u>~</u> , <u>~</u> , <u>~</u> ,		
(PAL)	<u>E 2~E4</u> , <u>X~Z+2</u> , <u>S1~S10</u> , <u>E5~E12</u> , <u>S11~S41</u> , <u>E21~E69</u>		
Tuning System			
<input checked="" type="checkbox"/> Frequency syn.	<input type="checkbox"/> Voltage syn.	<input type="checkbox"/> Others	

G-17.Preset Channel

80 channels

G-18.Intermediate Frequency

Picture(FP)	<u>38.9</u> MHz	<u> </u> MHz	<u> </u> MHz
Sound (FS)	<u>33.4</u> MHz	<u> </u> MHz	<u> </u> MHz
FP-FS	<u>5.5</u> MHz	<u> </u> MHz	<u> </u> MHz

G-19.Stereo/Dual TV Sound

Yes(NICAM) GERMAN USA JAPAN) No

G-20.Video Signal

Input Level	<u>1</u> Vp-p / <u>75</u> ohm
Output Level	<u>1</u> Vp-p / <u>75</u> ohm
S/N Ratio	<u>53</u> dB (Weighted)
Horizontal Resolution at SP Mode	<u>240</u> Lines

G-21.Audio Signal

Input Level	
Line	<u>-3.8</u> dB / <u>50</u> Kohm
RCA	<u>-</u> dB / <u>-</u> Kohm

Output Level	
Line	<u>-3.8</u> dB / <u>1</u> Kohm
RCA	<u>-</u> dB / <u>-</u> Kohm

(0dB=0.775 V rms)

S/N Ratio at SP Mode 42 dB

Harmonic Distortion : 1.5 % (1KHz)

Frequency Response :	at SP Mode	<u>100</u> Hz ~ <u>10</u> KHz
	at LP Mode	<u> </u> Hz ~ <u> </u> KHz
	at SLP Mode	<u> </u> Hz ~ <u> </u> KHz

G-22.Heads

Video	<input checked="" type="checkbox"/> <u>2</u> Rotary Heads
FM Audio	<input type="checkbox"/> <u> </u> Rotary Heads
Audio / Control	<input checked="" type="checkbox"/> <u>1</u> Stationary Head (<input checked="" type="checkbox"/> Mono <input type="checkbox"/> Stereo(L,R))
Erase	<input checked="" type="checkbox"/> <u>1</u> Full Track Erase

G-23.Motor: 3 Motors

Tape/Cassette Loading

Cylinder (Direct Drive)

Capstan (Direct Drive)

G-24.Power Source

<u>230</u> V	<input checked="" type="checkbox"/> AC 50Hz	<input type="checkbox"/> AC 60Hz
<input checked="" type="checkbox"/> EXT DC Jack	<u>12</u> V	

GENERAL SPECIFICATIONS

G-25.Power Consumption:
 (Approx.) 50 W at AC 230 V 50 Hz
50 W at DC 12 V
 (at TV and VCR ON)
 Stand by: 6 W at AC 230 V 50 Hz
 Per Year: - kWh / Year

G-26.Dimensions(Approx.)
287 mm(W) 333.5 mm(D) 319 mm(H)

G-27.Weight(Approx.) Net : 8.8 Kg (- lbs)
 Gross: 10.5 Kg (- lbs)

G-28.Cabinet Material

Cabinet Front:	<input checked="" type="checkbox"/> PS <input type="checkbox"/> ABS	<input checked="" type="checkbox"/> 94HB <input type="checkbox"/> 94V2 <input type="checkbox"/> 94V0	<input type="checkbox"/> DECABROM <input type="checkbox"/> NON-DECA
Cabinet Rear:	<input checked="" type="checkbox"/> PS <input type="checkbox"/> ABS	<input checked="" type="checkbox"/> 94HB <input type="checkbox"/> 94V2 <input type="checkbox"/> 94V0	<input type="checkbox"/> DECABROM <input type="checkbox"/> NON-DECA
Jack Panel:	<input checked="" type="checkbox"/> PS <input type="checkbox"/> ABS	<input checked="" type="checkbox"/> 94HB <input type="checkbox"/> 94V2 <input type="checkbox"/> 94V0	<input type="checkbox"/> DECABROM <input type="checkbox"/> NON-DECA

G-29.Cassette Loading System: Front Cassette Loading System
Top Loading System

G-30.Tape Counter: Linear Time Tape Counter

G-31.Protector: Power Fuse Dew Sensor

G-32.Regulation

Safety	<input type="checkbox"/> UL <input checked="" type="checkbox"/> BS <input type="checkbox"/> SEMKO <input type="checkbox"/> NOM	<input type="checkbox"/> CSA <input type="checkbox"/> NF <input type="checkbox"/> NZ <input type="checkbox"/> AS3159	<input type="checkbox"/> SAA <input type="checkbox"/> NEMKO <input type="checkbox"/> HOMOLO <input type="checkbox"/> DENTORI	<input type="checkbox"/> SI <input type="checkbox"/> FEMKO <input type="checkbox"/> SABS <input type="checkbox"/> UNE	<input checked="" type="checkbox"/> CE <input type="checkbox"/> DEMKO <input type="checkbox"/> CNS <input type="checkbox"/> GOST	<input type="checkbox"/> SEV <input type="checkbox"/> IEC65 <input type="checkbox"/> SISIR <input type="checkbox"/> NONE
Radiation	<input type="checkbox"/> FCC <input type="checkbox"/> SABA <input type="checkbox"/> CNS	<input type="checkbox"/> DOC <input type="checkbox"/> SI <input type="checkbox"/> CISPR13	<input type="checkbox"/> FTZ <input type="checkbox"/> NF <input type="checkbox"/> DENTORI	<input type="checkbox"/> PTT <input type="checkbox"/> NZ <input type="checkbox"/> AS/NZS	<input checked="" type="checkbox"/> CE <input type="checkbox"/> HOMOLO <input type="checkbox"/> NONE	<input type="checkbox"/> SEV <input type="checkbox"/> UNE
X-Radiation	<input type="checkbox"/> PTB	<input type="checkbox"/> DHHS	<input type="checkbox"/> HWC	<input type="checkbox"/> DENTORI	<input checked="" type="checkbox"/> NONE	

G-33.Temperature

Operation 5 °C ~ 40 °C
 Storage -20 °C ~ 60 °C

G-34.Operating Humidity

Less than 80 %RH

G-35.Clock and Timer

Built-in 1 Month 8 Events Programmable Timer

One Touch Recording : Max Time SP 5 Hours

Sleep Timer Yes Max 120 Min. (10 Min. Step) No

On/Off Timer Yes 1 Programs No

Wake Up Timer Yes Programs No

G-36.Timer back up Time

More than 30 Minutes (at Power Off Mode)

GENERAL SPECIFICATIONS

G-37.Terminals

<input checked="" type="checkbox"/> VHF/UHF Antenna	<input checked="" type="checkbox"/> Din Type	<input type="checkbox"/> F-Type	<input type="checkbox"/> France Type
<input checked="" type="checkbox"/> Front Video Input	(RCA ø8.3)		
<input checked="" type="checkbox"/> Front Audio Input	(RCA ø8.3)		
<input type="checkbox"/> Rear Video Input	(RCA ø8.3)		
<input type="checkbox"/> Rear Audio Input	(RCA ø8.3)		
<input type="checkbox"/> Rear Video Output	(RCA ø8.3)		
<input type="checkbox"/> Rear Audio Output	(RCA ø8.3)		
<input type="checkbox"/> Audio Output(Rear)		<input type="checkbox"/> Phono Jack (RCA ø8.3)	
<input checked="" type="checkbox"/> 21 Pin (x 1)		<input checked="" type="checkbox"/> DC Jack 12V (Center +)	
<input type="checkbox"/> AC Inlet		<input type="checkbox"/> Ext Speaker	
<input type="checkbox"/> Diversity		<input type="checkbox"/> Ear Phone	
<input checked="" type="checkbox"/> Head Phone			

G-38.Indicator

<input type="checkbox"/> Power (<u> </u>)	<input checked="" type="checkbox"/> Rec/OTR (<u>Red</u>)	<input type="checkbox"/> Play (<u> </u>)	<input type="checkbox"/> Tape-In (<u> </u>)	<input checked="" type="checkbox"/> Timer Rec (<u>Red</u>)
<input checked="" type="checkbox"/> Stand By (<u>Red</u>)	<input type="checkbox"/> On Timer (<u> </u>)	<input type="checkbox"/> Rental Mode(or Clear Picture) (<u> </u>)		
<input type="checkbox"/> One Touch Playback(Button Lights)		<input type="checkbox"/> Dew Sensor(Play LED Flush)		

G-39.On Screen Display

<input checked="" type="checkbox"/> Menu				
<input type="checkbox"/> ATS				
<input checked="" type="checkbox"/> Timer Rec Set				
<input checked="" type="checkbox"/> Ch Set-up				
	<input checked="" type="checkbox"/> Auto Tuning		<input type="checkbox"/> Ch Mapping	
	<input checked="" type="checkbox"/> Ch Tuning		<input checked="" type="checkbox"/> CH Allocation	
<input checked="" type="checkbox"/> TV Set-up				
	<input checked="" type="checkbox"/> On/Off Timer Set		<input type="checkbox"/> Audio	
	<input checked="" type="checkbox"/> Picture		<input type="checkbox"/> Tuning Mode	
<input checked="" type="checkbox"/> VCR Set-up				
	<input checked="" type="checkbox"/> Auto Repeat On/Off		<input type="checkbox"/> System Select	
	<input type="checkbox"/> Scena Repeat			
<input type="checkbox"/> User Registration				
<input checked="" type="checkbox"/> System Set-up				
	<input checked="" type="checkbox"/> Clock Set(<input checked="" type="checkbox"/> Calendar <input type="checkbox"/> 12H <input checked="" type="checkbox"/> 24H)			
	<input checked="" type="checkbox"/> Language			
<input type="checkbox"/> G-CODE(or SHOWVIEW or PLUSCODE)No. Entry(Option)				
<input checked="" type="checkbox"/> Clock	<input checked="" type="checkbox"/> CH/AV			
<input checked="" type="checkbox"/> Tape Counter		<input type="checkbox"/> Tape Speed		
<input checked="" type="checkbox"/> Sleep Time		<input checked="" type="checkbox"/> Sound Mute		
<input checked="" type="checkbox"/> Control Level (<input checked="" type="checkbox"/> Vol, <input checked="" type="checkbox"/> Bright, <input checked="" type="checkbox"/> Cont, <input checked="" type="checkbox"/> Color, <input type="checkbox"/> Tint, <input checked="" type="checkbox"/> Sharpness)				
<input checked="" type="checkbox"/> Play/Stop/FF/Rew/Rec/OTR/T-Rec/Pause				
<input checked="" type="checkbox"/> Auto Tracking/Manual Tracking				
<input checked="" type="checkbox"/> Index	<input checked="" type="checkbox"/> Repeat		<input checked="" type="checkbox"/> DEW	
<input type="checkbox"/> Tone 1/2	<input type="checkbox"/> Stereo			

G-40.OSD Language

Eng Ger Fre Spa Ita Por

OSD Language Setting

Eng Ger Fre Spa Ita Por

G-41.Speaker

Layout Front Side Bottom

Size/Peace 3 inches x 1 pcs

Imp 8 ohm

Power Max 1.2 W Typical / 10% 0.8 W Typical

GENERAL SPECIFICATIONS

G-42.EXT Speaker

Yes _____ W/Imp _____ ohm None

G-43.Carton

Master Carton: Need No Need

Content: _____ Set

Material: _____ / _____ Corrugated Carton

Dimensions: _____ mm(W) _____ mm(D) _____ mm(H)

Description of Origin Yes No

Gift Box

Material Double/Brown Corrugated Carton (with Photo Label)

Double/White Corrugated Carton (with Photo Label)

Double Full Color Carton W/Photo

Dimensions: 347 mm(W) 408 mm(D) 392 mm(H)

Design: As Per BUYER's

Description of Origin: Yes No

Drop Test Natural Dropping At 1 Corner / 3 Edges / 6 Surfaces

Height 25cm 31cm 46cm 62cm 80cm

Container Stuffing: 1160 Sets / 40' container

G-44.Accessories

Owner's Manual(W/ Guarantee Card) [German/French/English/Italian/Spanish]

Channel Film Dew Caution Sheet

Remote Control Unit AC Plug Adaptor

U/V Mixer Quick Set-up Sheet

Rod Antenna (One Pole Two Pole/F-Type DIN Type France Type)

Loop Antenna(F-Type DIN Type France Type)

DC Car Cord (Center+) Battery (UM-4 x 2)

Guarantee Card AC Cord

Warning Sheet AV Cord (2Pin-1Pin)

Circuit Diagram Registration Card

Antenna Change Plug PTB Sheet

Service Facility List 300 ohm to 75 ohm Antenna Plug

RF Cable Euro Warranty Information Sheet

G-45.Other Features

Auto Head Cleaning

Index Search

Auto Tracking

Auto Search

CH Auto Set-Up/Auto Clock

ATS

VIDEO PLUS+(SHOWVIEW,G-CODE) (Option)

VPS PDC

HQ (VHS Standard High Quality)

Auto Power On, Auto Play, Auto Rewind, Auto Eject, Auto Repeat System

PDC

Forward / Reverse Picture Search

SQPB

One Touch Playback

CATV

Auto CH Memory

Anti-Theft

Rental Mode

T'Text(Fast,Top,Uni)

TV Auto Shut off Function

TV Monitor

GENERAL SPECIFICATIONS

G-46.Switch

Front

- | | | |
|---|--|---|
| <input checked="" type="checkbox"/> Power(Tact) | <input checked="" type="checkbox"/> Channel Up | <input checked="" type="checkbox"/> Volume Up |
| <input checked="" type="checkbox"/> Play | <input checked="" type="checkbox"/> Channel Down | <input checked="" type="checkbox"/> Volume Down |
| <input type="checkbox"/> Pause/Still | <input checked="" type="checkbox"/> F.FWD/Cue | <input checked="" type="checkbox"/> Rew/Rev |
| <input type="checkbox"/> System Select | <input checked="" type="checkbox"/> Eject/Stop | <input checked="" type="checkbox"/> Rec/OTR |
| <input type="checkbox"/> One Touch Playback | <input type="checkbox"/> Main Power SW | |

Rear

- | | |
|--|----------------------------------|
| <input type="checkbox"/> Color On/Off (SECAM only) | <input type="checkbox"/> Degauss |
| <input checked="" type="checkbox"/> Main Power SW | |

- | |
|---|
| <input checked="" type="checkbox"/> AC/DC |
|---|

G-47.Magnetic Field

- | | | |
|---|--------------------------------------|--------------------------------------|
| <input checked="" type="checkbox"/> BV : +0.45G | <input type="checkbox"/> BV : +0.35G | <input type="checkbox"/> BV : +0.25G |
| BH : 0.18G | BH : 0.30G | BH : 0.30G |
| <input type="checkbox"/> BV : -0.15G | <input type="checkbox"/> BV : -0.25G | <input type="checkbox"/> BV : -0.50G |
| BH : 0.15G | BH : 0.15G | BH : 0.30G |

G-48.Remote Control Unit:

Glow in Dark Remocon

RC-CH

Power Source:

Yes

No

Total: 36 Key

D.C 3 V Battery UM - 4 x 2


- | | | |
|---|--|---|
| <input checked="" type="checkbox"/> 0/AV | <input checked="" type="checkbox"/> Ch/Tr/Page Up | <input checked="" type="checkbox"/> Power |
| <input checked="" type="checkbox"/> 1 | <input checked="" type="checkbox"/> Ch/Tr/Page Down | <input checked="" type="checkbox"/> Eject |
| <input checked="" type="checkbox"/> 2 | <input checked="" type="checkbox"/> Volume Up | <input type="checkbox"/> Play |
| <input checked="" type="checkbox"/> 3 | <input checked="" type="checkbox"/> Volume Down | <input type="checkbox"/> Play/Up |
| <input checked="" type="checkbox"/> 4 | <input checked="" type="checkbox"/> Muting | <input type="checkbox"/> Play/Slow/Up |
| <input checked="" type="checkbox"/> 5 | <input checked="" type="checkbox"/> Menu | <input type="checkbox"/> F.FWD |
| <input checked="" type="checkbox"/> 6 | <input checked="" type="checkbox"/> Enter/Hold | <input checked="" type="checkbox"/> F.FWD/Right |
| <input checked="" type="checkbox"/> 7 | <input checked="" type="checkbox"/> Cancel/Ch Skip/F/T/B | <input type="checkbox"/> Rew |
| <input checked="" type="checkbox"/> 8 | <input type="checkbox"/> Set Up | <input checked="" type="checkbox"/> Rew/Left |
| <input checked="" type="checkbox"/> 9 | <input type="checkbox"/> Set Down | <input checked="" type="checkbox"/> Pause/Still |
| <input type="checkbox"/> ... | <input type="checkbox"/> Set Right | <input type="checkbox"/> Pause |
| <input checked="" type="checkbox"/> Call | <input type="checkbox"/> Set Left | <input type="checkbox"/> Stop |
| <input checked="" type="checkbox"/> TV Monitor | <input checked="" type="checkbox"/> Program | <input checked="" type="checkbox"/> Stop/Down |
| <input checked="" type="checkbox"/> Sleep Timer | <input type="checkbox"/> Speed | <input checked="" type="checkbox"/> REC/OTR |
| <input checked="" type="checkbox"/> Timer Rec | <input checked="" type="checkbox"/> Text/Mix/TV | <input checked="" type="checkbox"/> ATR/Reveal |
| <input checked="" type="checkbox"/> Counter Reset | | |
| <input type="checkbox"/> AD Skip | <input checked="" type="checkbox"/> Zero Return | <input checked="" type="checkbox"/> Index/Time Text |

DISASSEMBLY INSTRUCTIONS

1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

1-1: BACK CABINET (Refer to Fig. 1-1)


1. Remove the 4 screws ①.
2. Remove the 2 screws ②.
3. Remove the 2 screws ③ which are used for holding the Back Cabinet.
4. Remove the AC cord from the AC cord hook ④.
5. Remove the Back Cabinet in the direction of arrow.



1-2: CRT PCB (Refer to Fig. 1-2)


**CAUTION: BEFORE REMOVING THE ANODE CAP, DISCHARGE ELECTRICITY BECAUSE IT CONTAINS HIGH VOLTAGE.
BEFORE ATTEMPTING TO REMOVE OR REPAIR ANY PCB, UNPLUG THE POWER CORD FROM THE AC SOURCE.**

1. Remove the Anode Cap.
(Refer to REMOVAL OF ANODE CAP)
2. Disconnect the following connectors:
(CP801 and CP850).
3. Remove the CRT PCB in the direction of arrow.




1-3: TV/VCR BLOCK (Refer to Fig. 1-3)

1. Remove the 2 screws ①.
2. Disconnect the following connectors:
(CP351, CP757, CP302, CP403 and CP401).
3. Unlock the support ②.
4. Remove the TV/VCR Block in the direction of arrow.



1-4: MAIN PCB (Refer to Fig. 1-4)


1. Remove the screw ①.
2. Remove the Main PCB Holder.
3. Remove the 3 screws ②.
4. Disconnect the following connectors:
(CP810, CP820, CP404, CP501 and CP601).
5. Remove the Main PCB in the direction of arrow.



DISASSEMBLY INSTRUCTIONS


1-5: DECK SHIELD PLATE AND BOTTOM SHIELD PLATE (Refer to Fig. 1-5)

1. Remove the 2 screws ①.
2. Remove the 4 screws ②.
3. Remove the screw ③.
4. Remove the Deck Shield Plate in the direction of arrow (A).
5. Remove the screw ④.
6. Remove the Bottom Shield Plate in the direction of arrow (B).




1-6: DECK CHASSIS (Refer to Fig. 1-6)

1. Remove the 3 screws ①.
2. Disconnect the following connectors:
(CP1001, CD1002, CP1004, CP1005, CP1006, CP4001, CP4004 and CP4005).
3. Remove the Deck Chassis in the direction of arrow.



1-7: JACK PLATE AND SYSCON PCB (Refer to Fig. 1-7)

1. Remove the screw ①.
2. Remove the Syscon PCB in the direction of arrow (A).
3. Remove the 2 screws ②.
4. Unlock the 2 supports ③.
5. Remove the Jack Plate in the direction of arrow (B).



DISASSEMBLY INSTRUCTIONS


2. REMOVAL OF DECK PARTS

2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Remove the 2 screws ①.
2. Slide the 2 supports ② and remove the Top Bracket.


NOTE

When you install the Top Bracket, install the screw (1) first, then install the screw (2).




2-2: FLAP LEVER/TAPE GUIDE R (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the back side.
2. Remove the Polyslider Washer ①.
3. Remove the Flap Lever.
4. Unlock the 3 supports ② and remove the Tape Guide R.




2-3: TAPE GUIDE L (Refer to Fig. 2-3-A)

1. Move the Cassette Holder Ass'y to the back side.
2. Unlock the 2 supports ① and remove the Tape Guide L.
3. Remove the REC Lever. (Recorder only)




NOTE

When you install the Tape Guide L, install as shown in the circle of Fig. 2-3-B. (Refer to Fig. 2-3-B)



2-4: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-4)

1. Move the Cassette Holder Ass'y to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




2-5: CASSETTE SIDE L/R (Refer to Fig. 2-5)

1. Remove the Locker Spring.
2. Unlock the 4 supports ① and then remove the Cassette Side L/R.

NOTE


When you install the Cassette Side L/R, be sure to move the Locker L/R after installing.



DISASSEMBLY INSTRUCTIONS


2-6: LINK ASS'Y (Refer to Fig. 2-6)

- Set the Link Ass'y to the Eject position.
- Remove the (A) side of the Link Ass'y first, then remove the (B) side.




2-7: LOADING MOTOR ASS'Y (Refer to Fig. 2-7)

- Remove the Link Lever.
- Remove the Dumper Spring.
- Remove the 2 screws ①.
- Unlock the support ② and remove the Loading Motor Ass'y.
- Unlock the 2 supports ③ and remove the Deck PCB (BOT).




2-8: SENSOR COVER L (Refer to Fig. 2-8)

- Unlock the support ① and remove the Sensor Cover L.
- Unlock the 2 supports ② and remove the Deck PCB (EOT).




2-9: TENSION ASS'Y (Refer to Fig. 2-9-A)

- Move the Inclined S Ass'y to the back side.
- Unlock the support ① and remove the S Reel Stopper.
- Remove the Tension Spring.
- Unlock the support ② and remove the Tension Arm Ass'y.
- Remove the Tension Adjust.
- Unlock the 2 supports ③ and remove the Tension Band Ass'y.
- Unlock the support ④ and remove the Tension Holder.




NOTE

When you install the Tension Adjust, install as shown in Fig. 2-9-B. (Refer to Fig. 2-9-B)



2-10: T BRAKE ASS'Y (Refer to Fig. 2-10)

- Remove the T Brake Spring.
- Remove the T Brake Ass'y.



DISASSEMBLY INSTRUCTIONS

2-11: S REEL/T REEL ASS'Y (Refer to Fig. 2-11)

1. Remove the Idler Ass'y.
2. Remove the S Reel and T Reel Ass'y.
3. Remove the 2 Polyslider Washers ①.

NOTE

1. Take care not to damage the gears of the S Reel, T Reel Ass'y and Idler Ass'y.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel Ass'y. (Use gloves.) (Refer to Fig. 2-11) Do not adhere the stains on it.
5. When you install the reel, clean the shaft and oil it (KYODO OIL Slidas #150). (If you do not oil, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)




Fig. 2-11

2-12: PINCH ROLLER ASS'Y/P5 ARM ASS'Y (Refer to Fig. 2-12-A)

1. Remove the P5 Spring.
2. Remove the screw ①.
3. Unlock the 2 supports ② and remove the Cassette Opener.
4. Remove the Pinch Roller Ass'y, Pinch Roller Lever and P5 Arm Ass'y.




Fig. 2-12-A

NOTE

1. Do not touch the Pinch Roller. (Use gloves.)
2. When you install the Pinch Roller Ass'y, install as shown in the circle. (Refer to Fig. 2-12-B)




Fig. 2-12-B

2-13: A/C HEAD (Refer to Fig. 2-13-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.

NOTE

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-13-B. (Refer to Fig. 2-13-B)
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).




Fig. 2-13-A




Fig. 2-13-B

2-14: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-14)

1. Remove the screw ①.
2. Remove the FE Head.




Fig. 2-14


DISASSEMBLY INSTRUCTIONS

2-15: AHC ASS'Y/CYLINDER UNIT ASS'Y (Refer to Fig. 2-15)

1. Unlock the support ① and remove the AHC Ass'y.
2. Remove the 3 screws ②.
3. Remove the Cylinder Unit Ass'y.


NOTE

When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.



2-16: CAPSTAN DD UNIT (Refer to Fig. 2-16)

1. Remove the Capstan Belt.
2. Remove the 3 screws ①.
3. Remove the Capstan DD Unit.



2-17: MIDDLE GEAR/MAIN CAM (Refer to Fig. 2-17-A)

1. Remove the Polyslider Washer ①, then remove the Middle Gear.
2. Remove the E-Ring, then remove the Main Cam, Link Lever Spacer and P5 Cam.
3. Remove the Polyslider Washer ②, then remove the Pinch Roller Cam.
4. Remove the Polyslider Washer ③, then remove the Joint Gear.




Fig. 2-17-A

NOTE

When you install the Pinch Roller Cam, P5 Cam and Main Cam, align each marker. (Refer to Fig. 2-17-B)




Fig. 2-17-B

2-18: CLUTCH ASS'Y (Refer to Fig. 2-18)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Ass'y, Ring Spring, Ring Clutch, Gear Clutch and Polyslider Washer ②.

NOTE

When you install the Clutch Ass'y, oil the shaft (KYODO OIL Slidas #150).




Fig. 2-18

DISASSEMBLY INSTRUCTIONS

2-19: LOADING GEAR S/T ASS'Y (Refer to Fig. 2-19-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Capstan Brake Spring.
3. Slide the Main Rod and remove the Capstan Brake Arm Ass'y.
4. Remove the Main Rod.
5. Remove the Tension Lever.
6. Unlock the 2 supports ② and remove the Clutch Lever.
7. Remove the screw ③.
8. Remove the LED Reflector.
9. Remove the Loading Arm S Ass'y and Loading Arm T Ass'y.
10. Remove the Loading Gear S and Loading Gear T.
11. Remove the Loading Gear Spring.




Fig. 2-19-A

NOTE

When you install the Loading Arm S Ass'y, Loading Arm T Ass'y and Main Loading Gear, align each marker. (Refer to Fig. 2-19-B)




Fig. 2-19-B

2-20: INCLINED S/T ASS'Y (Refer to Fig. 2-20)

1. Unlock the support ① and remove the P4 Cover.
2. Remove the S-S Brake Spring.
3. Unlock the support ② and remove the Loading Gear Holder.
4. Remove the S-S Brake Arm.
5. Remove the Inclined S.
6. Remove the Inclined T.
7. Remove the 2 screws ③, then remove the Guide Roller.

NOTE

Do not touch the roller of Guide Roller.




Fig. 2-20

DISASSEMBLY INSTRUCTIONS

3. REMOVAL OF ANODE CAP

Read the following **NOTED** items before starting work.

- * After turning the power off there might still be a potential voltage that is very dangerous. When removing the Anode Cap, make sure to discharge the Anode Cap's potential voltage.
- * Do not use pliers to loosen or tighten the Anode Cap terminal, this may cause the spring to be damaged.

REMOVAL

1. Follow the steps as follows to discharge the Anode Cap. **(Refer to Fig. 3-1.)**

Connect one end of an Alligator Clip to the metal part of a flat-blade screwdriver and the other end to ground. While holding the plastic part of the insulated Screwdriver, touch the support of the Anode with the tip of the Screwdriver.

A cracking noise will be heard as the voltage is discharged.




Fig. 3-1

2. Flip up the sides of the Rubber Cap in the direction of the arrow and remove one side of the support. **(Refer to Fig. 3-2.)**




Fig. 3-2

3. After one side is removed, pull in the opposite direction to remove the other.

NOTE

Take care not to damage the Rubber Cap.

INSTALLATION

1. Clean the spot where the cap was located with a small amount of alcohol. **(Refer to Fig. 3-3.)**




Fig. 3-3

NOTE

Confirm that there is no dirt, dust, etc. at the spot where the cap was located.

2. Arrange the wire of the Anode Cap and make sure the wire is not twisted.
3. Turn over the Rubber Cap. **(Refer to Fig. 3-4.)**




Fig. 3-4

DISASSEMBLY INSTRUCTIONS

4. Insert one end of the Anode Support into the anode button, then the other as shown in **Fig. 3-5**.




Fig. 3-5

5. Confirm that the Support is securely connected.
6. Put on the Rubber Cap without moving any parts.

4. REMOVAL OF DEFLECTION YOKE

(Refer to Fig. 4-1)

1. Loosen the screw ①.
2. Remove the Convergence • Purity Magnet in the direction of arrow (A).
3. Loosen the screw ②.
4. Remove the 3 Wedges.
5. Remove the Deflection Yoke in the direction of arrow (B).




Fig. 4-1

INSTALLATION

Install new Deflection Yoke in reverse steps of REMOVAL.

NOTE

After adjusting the purity and the convergence, fix the screw ② and lock the wedges.

KEY TO ABBREVIATIONS

A	A/C	: Audio/Control	H.SW	: Head Switch
	ACC	: Automatic Color Control	Hz	: Hertz
	AE	: Audio Erase	I	: Integrated Circuit
	AFC	: Automatic Frequency Control	IF	: Intermediate Frequency
	AFT	: Automatic Fine Tuning	IND	: Indicator
	AFT DET	: Automatic Fine Tuning Detect	INV	: Inverter
	AGC	: Automatic Gain Control	K	: Killer
	AMP	: Amplifier	L	: Left
	ANT	: Antenna	LED	: Light Emitting Diode
	A.PB	: Audio Playback	LIMIT AMP	: Limiter Amplifier
	APC	: Automatic Phase Control	LM, LDM	: Loading Motor
	ASS'Y	: Assembly	LP	: Long Play
	AT	: All Time	L.P.F	: Low Pass Filter
	AUTO	: Automatic	LUMI.	: Luminance
	A/V	: Audio/Video	M	: Motor
B	BGP	: Burst Gate Pulse	MAX	: Maximum
	BOT	: Beginning of Tape	MINI	: Minimum
	BPF	: Bandpass Filter	MIX	: Mixer, mixing
	BRAKE SOL	: Brake Solenoid	MM	: Monostable Multivibrator
	BUFF	: Buffer	MOD	: Modulator, Modulation
	B/W	: Black and White	MPX	: Multiplexer, Multiplex
C	C	: Capacitance, Collector	MS SW	: Mecha State Switch
	CASE	: Cassette	N	: Non Connection
	CAP	: Capstan	NC	: Noise Reduction
	CARR	: Carrier	NR	: Oscillator
	CH	: Channel	O	: Operation
	CLK	: Clock	OSC	: Playback
	CLOCK (SY-SE)	: Clock (Syscon to Servo)	PB	: Playback Control
	COMB	: Combination, Comb Filter	PB CTL	: Playback-Chrominance
	CONV	: Converter	PB-C	: Playback-Luminance
	CPM	: Capstan Motor	PB-Y	: PCB
	CTL	: Control	PCB	: Printed Circuit Board
	CYL	: Cylinder	P. CON	: Power Control
	CYL-M	: Cylinder-Motor	PD	: Phase Detector
	CYL SENS	: Cylinder-Sensor	PG	: Pulse Generator
D	DATA (SY-CE)	: Data (Syscon to Servo)	P-P	: Peak-to Peak
	dB	: Decibel	R	: Right
	DC	: Direct Current	REC	: Recording
	DD Unit	: Direct Drive Motor Unit	REC-C	: Recording-Chrominance
	DEMOD	: Demodulator	REC-Y	: Recording-Luminance
	DET	: Detector	REEL BRK	: Reel Brake
	DEV	: Deviation	REEL S	: Reel Sensor
E	E	: Emitter	REF	: Reference
	EF	: Emitter Follower	REG	: Regulated, Regulator
	EMPH	: Emphasis	REW	: Rewind
	ENC	: Encoder	REV, RVS	: Reverse
	ENV	: Envelope	RF	: Radio Frequency
	EOT	: End of Tape	RMC	: Remote Control
	EQ	: Equalizer	RY	: Relay
	EXT	: External	S	: Serial Clock
F	F	: Fuse	S. CLK	: Sensor Common
	FBC	: Feed Back Clamp	S. COM	: Serial Data
	FE	: Full Erase	S. DATA	: Segment
	FF	: Fast Forward, Flipflop	SEG	: Select, Selector
	FG	: Frequency Generator	SEL	: Sensor
	FL SW	: Front Loading Switch	SENS	: Search Mode
	FM	: Frequency Modulation	SER	: Serial Input
	FSC	: Frequency Sub Carrier	SI	: Sound Intermediate Frequency
	FWD	: Forward	SIF	: Serial Output
G	GEN	: Generator	SO	: Solenoid
	GND	: Ground	SOL	: Standard Play
H	H.P.F	: High Pass Filter	SP	: Serial Strobe
			STB	: Switch
			SW	

KEY TO ABBREVIATIONS

S	SYNC	: Synchronization
	SYNC SEP	: Sync Separator, Separation
T	TR	: Transistor
	TRAC	: Tracking
	TRICK PB	: Trick Playback
	TP	: Test Point
U	UNREG	: Unregulated
V	V	: Volt
	VCO	: Voltage Controlled Oscillator
	VIF	: Video Intermediate Frequency
	VP	: Vertical Pulse, Voltage Display
	V.PB	: Video Playback
	VR	: Variable Resistor
	V.REC	: Video Recording
	VSF	: Visual Search Fast Forward
	VSR	: Visual Search Rewind
	VSS	: Voltage Super Source
	V-SYNC	: Vertical-Synchronization
	VT	: Voltage Tuning
X	X'TAL	: Crystal
Y	Y/C	: Luminance/Chrominance

SERVICE MODE LIST

This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.

To enter SERVICE MODE, unplug AC cord till lost actual clock time. Then press and hold Vol (-) button of main unit and remocon key simultaneously.

The both pressing of set key and remote control key will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.

Set Key	Remocon Key	Operations
VOL. (-) MIN	1	Initialization of the factory. NOTE: Do not use this for the normal servicing.
VOL. (-) MIN	2	Horizontal position adjustment of OSD. NOTE: Also can be adjusted by using the Adjustment MENU. Refer to the "ELECTRICAL ADJUSTMENT" (OSD HORIZONTAL).
VOL. (-) MIN	3	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	4	Adjust the PG SHIFTER manually. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	5	Adjusting of the Tracking to the center position. NOTE: Also can be adjusted by pressing the ATR button for more than 2 seconds during PLAY.
VOL. (-) MIN	6	POWER ON total hours and PLAY/REC total hours are displayed on the screen. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF USING HOURS). Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "NOTE FOR THE REPLACING OF MEMORY IC".
VOL. (-) MIN	7	Releasing of PROTECTION PASSWORD.
VOL. (-) MIN	8	Writing of EEPROM initial data. NOTE: Do not use this for the normal servicing.
VOL. (-) MIN	9	Display of the Adjustment MENU on the screen. Refer to the "ELECTRICAL ADJUSTMENT" (On-Screen Display Adjustment).

Method	Operations
Press the ATR button on the remote control for more than 2 seconds during PLAY.	Adjusting of the Tracking to the center position. Refer to the "MECHANICAL ADJUSTMENT" (GUIDE ROLLER) and "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
Make the short circuit between the test point of SERVICE and the GND.	The EOT/BOT/Reel sensor do not work at this moment. Refer to the "PREPARATION FOR SERVICING"

PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage. Unless maintenance is properly carried out, the following service intervals may be quite shortened as harmful effects may be had on other parts. Also, long term storage or misuse may cause transformation and aging of rubber parts.

Parts Name \ Time	500 hours	1,000 hours	1,500 hours	2,000 hours	3,000 hours	Notes
Audio Control Head	■	■	■	■	■	
Full Erase Head (Recorder only)	■	■	■	■	■	Clean those parts in contact with the tape.
Capstan Belt			■	■	●	
Pinch Roller	■	■	■	■	■ ●	Clean the rubber, and parts which the rubber touches.
Capstan DD Unit					●	
Loading Motor					●	
Tension Band					●	
Capstan Shaft	■	■	■	■	■	
Tape Running Guide Post	■	■	■	■	■	Replace when rolling becomes abnormal.
Cylinder Unit	■	■	■	■	●	Clean the Head

■ : Clean
● : Replace


CONFIRMATION OF USING HOURS

POWER ON total hours and PLAY/REC total hours can be checked on the screen.

Total hours are displayed in 16 system of notation.

NOTE: The confirmation of using hours will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.

1. Set the VOLUME to minimum.
2. Press both VOL. DOWN button on the set and the Channel button (6) on the remote control simultaneously.
3. After the confirmation of using hours, turn off the power.



(16 x 16 x 16 x thousands digit value) + (16 x 16 x hundreds digit value) + (16 x tens digit value) + (ones digit value)

PREVENTIVE CHECKS AND SERVICE INTERVALS


CLEANING

NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

1. AUDIO CONTROL HEAD

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol and clean the audio control head by wiping it horizontally. Clean the full erase head in the same manner. (Refer to the figure below.)



2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). (Refer to the figure below.)

NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



NOTE FOR THE REPLACING OF MEMORY IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

NOTE: Initial Data setting will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.

ADDRESS	DATA										
00	00	0C	00	18	A3	24	00	30	04	3C	6C
01	16	0D	F3	19	89	25	5F	31	04	3D	2B
02	04	0E	35	1A	36	26	00	32	20	3E	21
03	C5	0F	66	1B	5F	27	F0	33	1B	3F	15
04	00	10	A6	1C	0A	28	0A	34	00		
05	00	11	AE	1D	F0	29	F3	35	3A		
06	00	12	00	1E	05	2A	01	36	00		
07	2D	13	3F	1F	F3	2B	00	37	40		
08	C4	14	80	20	00	2C	00	38	00		
09	21	15	2A	21	00	2D	01	39	00		
0A	41	16	00	22	00	2E	06	3A	00		
0B	0C	17	35	23	00	2F	01	3B	00		

Table 1

1. Enter DATA SET mode by setting VOLUME to minimum.
2. While holding down VOLUME button on front cabinet, press key 6 on remote control simultaneously. ADDRESS and DATA should appear as FIG 1.














Fig. 1

3. ADDRESS is now selected and should "blink". Using the PLAY or STOP button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
4. Press ENTER to select DATA. When DATA is selected, it will "blink".
5. Again, step through the DATA using PLAY or STOP button until required DATA value has been selected.
6. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
7. Repeat steps 3 to 6 until all data has been checked.
8. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input. The unit will now have the correct DATA for the new MEMORY IC.

SERVICING FIXTURES AND TOOLS

<p>(For 2 head 1 speed model, 4 head model)</p> <p>VHS Alignment Tape JG001E (VP₁S-LI6³) JG001F (VP₁S-CO1³) JG001R (VP₁S-LI6³H) JG001U (VP₁S-X6³)</p> 	<p>(For 2 head 2 speed model)</p> <p>VHS Alignment Tape JG001C (VP₂S-LI6³) JG001D (VP₂S-CO1³) JG001V (VP₂S-X6³)</p> 	<p>JG002B Adapter JG002E Dial Torque Gauge (10~90gf•cm) JG002F (60~600gf•cm)</p> 	<p>JG005 Post Adjustment Screwdriver Part No. SV-TG0-030-000 (small)</p> 
<p>JG153 X Value Adjustment Screwdriver</p> 	<p>JG022 Master Plane</p> 	<p>JG024A Reel Disk Height Adjustment Jig</p> 	<p>JG100A Torque Tape (VHT-063)</p> 
<p>JG154 Cable</p> 	<p>JG162C Cable (10 Pins) JG162D Cable (11 Pins) JG162Y Cable (5 Pins)</p> 	<p>Tentelometer</p> 	

Part No.	Remarks
JG001E	Monoscope, 6KHz (For 2 head 1 speed model, 4 head model)
JG001F	Color Bar, 1KHz (For 2 head 1 speed model, 4 head model)
JG001R	Hi-Fi Audio (For Hi-Fi model)
JG001U	X Value Adjustment (For 2 head 1 speed model, 4 head model)
JG001C	Monoscope, 6KHz (For 2 head 2 speed model)
JG001D	Color Bar, 1KHz (For 2 head 2 speed model)
JG001V	X Value Adjustment (For 2 head 2 speed model)
JG002B	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	Brake Torque (T Reel Ass'y)
JG002F	VSR Torque, Brake Torque (S Reel)
JG005	Guide Roller Adjustment
JG153	X Value Adjustment
JG022/JG024A	Reel Disk Height Adjustment
JG100A	Playback Torque, Back Tension Torque During Playback
JG154	Used to connect the test point of SERVICE and GROUND
JG162C/JG162D	Used to connect the Syscon PCB and Main PCB
JG162Y	Used to connect the Syscon PCB and CRT PCB

PREPARATION FOR SERVICING


How to use the Servicing Fixture

1. Unplug the connector CP351, CP757, CP302 and CP403, then remove the TV/VCR Block from the set.
2. Unplug the connector CP810, CP820 and CP850, then remove the Main PCB from the VCR Block.
3. Connect as shown in the below figure using the Service Fixture.
 - Connect the Syscon PCB to the Main PCB with the cable JG162C and JG162D.
 - Connect the Syscon PCB to the CRT PCB with the cable JG162Y.
4. Remove the Operation PCB from the set, then connect it with the Syscon PCB.
If necessary, connect CP351 (Front A/V Jack Input Terminal)
5. Short circuit between **TP1001** and **Ground** with the cable JG154.

(Refer to MAJOR COMPONENTS LOCATION GUIDE)

The EOT, BOT and Reel Sensor do not work at this moment.

6. At that time, the STOP/EJECT button is available to insert and eject the Cassette Tape.



MECHANICAL ADJUSTMENTS



1. CONFIRMATION AND ADJUSTMENT

Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)
- When you activate the deck without the Cassette Holder, short circuit between **TP1001** and **GND**. (**Refer to ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE**) In this condition the BOT/EOT/Reel Sensor will not function.



1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

1. Turn on the power and set to the STOP mode.
2. Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
3. Confirm that "A" of the reel disk is lower than "B" of the reel disk height adjustment jig (**JG024A**), and is higher than "C". If it is not enough height, adjust to $10(+0.2, -0)$ mm with the height adjustment washer.
4. Adjust the other reel in the same way.




1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

1. Set to the PLAY mode.
2. Adjust the Tension Adjust until the edge of the Tension Arm is positioning within 0.5mm range from the standard line center of Main Chassis. After this adjustment, confirm that the cut position is located in "A" area as shown in **Fig. 1-2-B**. If it is located in "B" area, adjust again.
3. While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.



1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

1. Load a video tape (E-180) recorded in standard speed mode. Set the unit to the PLAY mode.
 2. Install the tentelometer as shown in **Fig. 1-3**. Confirm that the meter indicates 20 ± 2 gf·cm in the beginning of playback.
- USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)
1. After confirmation and adjustment of Tension Post position (**Refer to item 1-2**), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
 2. Confirm that the right meter of the torque tape indicates 60~100gf·cm during playback in SP mode.
 3. Confirm that the left meter of the torque tape indicates 25~40gf·cm during playback in SP mode.



MECHANICAL ADJUSTMENTS

1-4: CONFIRMATION OF VSR TORQUE

- Operate within 4~5 seconds after the reel disk begins to turn.
- Install the Torque Gauge (**JG002F**) and Adapter (**JG002B**) on the S Reel. Set to the Rewind mode. (**Refer to Fig.1-4**)
- Then, confirm that it indicates 120~180gf•cm.

NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.


1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (**Refer to Fig. 1-4**)

- Set to the STOP mode.
- Move the Idler Ass'y from the S Reel.
- Install the Torque Gauge (**JG002F**) and Adapter (**JG002B**) on the S Reel. Turn the Torque Gauge (**JG002F**) clockwise.
- Then, confirm that it indicates 70~100gf•cm.

(T Reel Brake) (**Refer to Fig. 1-4**)

- Set to the STOP mode.
- Move the Idler Ass'y from the T Reel Ass'y.
- Install the Torque Gauge (**JG002E**) and Adapter (**JG002B**) on the T reel. Turn the Torque Gauge (**JG002E**) counterclockwise.
- Then, confirm that it indicates 35~60gf•cm.



NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	T Brake Spring/Tension Spring

2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM



Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

2-1: GUIDE ROLLER

- Playback the VHS Alignment Tape (**JG001C** or **JG001E**). (**Refer to SERVICING FIXTURE AND TOOLS**)
- Connect CH-1 of the oscilloscope to **TP4002 (Envelope)** and CH-2 to **TP4001 (SW Pulse)**.
- Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
- Trigger with SW Pulse and observe the envelope. (**Refer to Fig. 2-1-A**)
- When observing the envelope, adjust the Adjusting Driver (**JG005**) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
- Adjust so that the A : B ratio is better than 3 : 2 as shown in **Fig. 2-1-B**, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
- Adjust the PG shifter during playback. (**Refer to the ELECTRICAL ADJUSTMENTS**)

NOTE

After adjustment, confirm and adjust A/C head. (**Refer to item 2-2**)



MECHANICAL ADJUSTMENTS

2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD

When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001C or JG001E**). **(Refer to SERVICING FIXTURE AND TOOLS)**
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
 - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
 - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
 - c) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.




Fig. 2-2-A




Fig. 2-2-B




Fig. 2-2-C

2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)


1. Confirm and adjust the height of the Reel Disk. **(Refer to item 1-1)**
2. Confirm and adjust the position of the Tension Post. **(Refer to item 1-2)**
3. Adjust the Guide Roller. **(Refer to item 2-1)**
4. Confirm and adjust the Audio/Control Head. **(Refer to item 2-2)**
5. Connect CH-1 of the oscilloscope to **TP4002**, CH-2 to **TP4001** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001U or JG001V**). **(Refer to SERVICING FIXTURE AND TOOLS)**
7. Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-1-A**.

2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP4002**, CH-2 to **TP4001** and CH-3 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001R**). **(Refer to SERVICING FIXTURE AND TOOLS)**
3. Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
6. Confirm that the difference between these counted steps number in the above items are within 2 steps. If the difference are more than 3 steps, do Tape Running Adjustment again. **(Refer to item 2-3)**

MECHANICAL ADJUSTMENTS

3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- | | |
|-----------------------------------|----------------------|
| 1. Tension Adjust | 7. P4 Post |
| 2. Tension Arm | 8. T Brake Spring |
| 3. Guide Roller | 9. T Reel Ass'y |
| 4. P1 Post | 10. Idler Ass'y |
| 5. Audio/Control Head | 11. S-S Brake Spring |
| 6. X value adjustment driver hole | 12. S Reel |

ELECTRICAL ADJUSTMENTS

1. ADJUSTMENT PROCEDURE

Read and perform these adjustments when repairing the circuits or replacing electrical parts or PCB assemblies.

CAUTION

When replacing IC's or transistors, use only specified silicon grease (**YG6260M**).

(To prevent the damage to IC's and transistors.)

On-Screen Display Adjustment

1. Unplug the AC plug for more than 30 minutes to set the clock to the non-setting state. Then, set the volume level to minimum.
2. Press the VOL. DOWN button on the set and the channel button **(9)** on the remote control simultaneously to display adjustment mode on the screen as shown in **Fig. 1-1**.

NOTE

Use the channel buttons **(1-8)** on the remote control to select the options shown in **Fig. 1-1**.

Press the channel button **(0)** on the remote control to end the adjustments.

- 1. H/V
- 2. AKB
- 3. COLOR TEMP
- 4. PICTURE
- 5. OTHERS
- 6. TEST PATTERN
- 7.
- 8. (VOL TEST) 0. END

Fig. 1-1

2. BASIC ADJUSTMENTS

(VCR SECTION)

2-1: PG SHIFTER

1. Connect CH-1 on the oscilloscope to **TP4001** and CH-2 to **TP4501**.
2. Playback the alignment tape. (**JG001C**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press the VOL. DOWN button on the set and the channel button **(3)** on the remote control simultaneously until the indicator REC disappears. If the indicator REC disappears, adjustment is completed.

(If the above adjustments doesn't work well:)

5. Press the VOL. DOWN button on the set and the channel button **(3)** on the remote control simultaneously until the indicator REC disappears.
6. When the REC indicator is blinking, press both VOL. DOWN button on the set and the channel button **(4)** on the remote control simultaneously and adjust the Tracking +/- button until the arising to the down of Head Switching Pulse becomes $6.5 \pm 0.5H$.
(Refer to Fig. 2-1-A, B)
7. Press the Tracking Auto button.




Fig. 2-1-A




Fig. 2-1-B

2-2: RF AGC DELAY

1. Receive the monoscope pattern.
2. Connect the digital voltmeter between the **pin 5 of CP603** and the **pin 1 (GND) of CP603**.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(5)** on the remote control. The **Fig. 2-2** appears on the display.
4. Press the channel button **(1)** on the remote control to select "RF AGC DELAY".
5. Press the PLAY or STOP button on the remote control until the digital voltmeter is $1.50 \pm 0.05V$ (80dB).

- 1. RF AGC DELAY
- 2. VIDEO LEVEL
- 3. FM LEVEL
- 4. OSD H
- 5. CUT OFF
- 6.
- 7.
- 8. 0. RETURN

Fig. 2-2

2-3: VCO FREERUN

1. Connect the oscillator to **pin 11 of TU601**.
2. Connect the digital voltmeter to **pin 47 of IC601**.
3. Adjust the **L608** until the digital voltmeter is $3.8 \pm 0.05V$.

(TV SECTION)

2-4: CONSTANT VOLTAGE (AC)

1. Using the remote control, set the brightness and contrast to normal position.
2. Connect the digital voltmeter to **TP401**.
3. Set condition is AV MODE without signal.
4. Adjust the **VR502** until the DC voltage is $DC 100 \pm 0.5V$.

2-5: CONSTANT VOLTAGE (DC)

1. Using the remote control, set the brightness and contrast to normal position.
2. Connect the digital voltmeter to **TP401**.
3. Set condition is AV MODE without signal.
4. Adjust the **VR501** until the DC voltage is $DC 100 \pm 0.5V$.

ELECTRICAL ADJUSTMENTS

2-6: CUT OFF

1. Place the set with Aging Test for more than 15 minutes.
2. Set condition is AV MODE without signal.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(5)** on the remote control. The **Fig. 2-2** appears on the display.
5. Press the channel button **(5)** on the remote control to select "CUT OFF".
6. Adjust the **Screen Volume** until a dim raster is obtained.

2-7: FOCUS

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Turn the Focus Volume fully counterclockwise once.
4. Adjust the **Focus Volume** until picture is distinct.

2-8: WHITE BALANCE

NOTE: Adjust after performing CUT OFF adjustments.

1. Place the set with Aging Test for more than 15 minutes.
2. Receive the white 100% signal from the Pattern Generator.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(2)** on the remote control to select "AKB". The **Fig. 2-3** appears on the display.
5. Press the channel button **(2)** on the remote control to select the "R.BIAS".
6. Using the SET +/- keys on the remote control, adjust the R.BIAS.
7. Press the CH. UP/DOWN button on the remote control to select the "G.BIAS", "B.BIAS", "R.DRIVE" or "B.DRIVE".
8. Using the SET +/- keys on the remote control, adjust the G.BIAS, B.BIAS, R.DRIVE or B.DRIVE.
9. Perform the above adjustment 7 and 8 until the white color is looked like a white.

1. AKB AUTO
 2. R. BIAS
 3. G. BIAS
 4. B. BIAS
 5. R. DRIVE
 6. G. DRIVE
 7. B. DRIVE
 8. AGC AUTO
0. RETURN

Fig. 2-3

2-9: SUB BRIGHTNESS

1. Receive the monoscope pattern. (RF Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-4** appears on the display.
4. Press the channel button **(1)** on the remote control to select "BRIGHT".
5. Press the PLAY or STOP button on the remote control until the white 25% is starting to be visible.
6. Receive the monoscope pattern. (Audio Video Input)
7. Press the AV button on the remote control to set to the AV mode. Then perform the above adjustments 2~5.

1. BRIGHT
2. CONTRAST
3. COLOR
4. TINT
5. SHARPNESS
6. OSD CONT
- 7.
8. 0. RETURN

Fig. 2-4

2-10: SUB COLOR

1. Receive the color bar pattern. (RF Input)
2. Connect the synchro scope to **TP801**.
3. Using the remote control, set the brightness, contrast and color to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-4** appears on the display.
5. Press the channel button **(3)** on the remote control to select "COLOR".
6. Adjust the VOLTS RANGE VARIABLE knob of the oscilloscope until the range between white 100% and 0% is set to 4 divisions on the screen of the oscilloscope.
7. Press the PLAY or STOP button on the remote control until the red level is set to the 4 divisions.
(Refer to Fig. 2-5)
8. Receive the monoscope pattern. (Audio Video Input)
9. Press the AV button on the remote control to set to the AV mode. Then perform the above adjustments 2~7.




Fig. 2-5

ELECTRICAL ADJUSTMENTS

2-11: HORIZONTAL PHASE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(1)** on the remote control to select "H. PHASE".
5. Press the PLAY or STOP button on the remote control until the SHIFT quantity of the OVER SCAN on right and left becomes minimum.

- 1. H. PHASE
- 2. H. BLK
- 3. V. SIZE
- 4. V. POSI
- 5. V. LIN
- 6. V. SC
- 7. V. COMP
- 8. (H FREQ) 0. RETURN

Fig. 2-6

2-12: VERTICAL SIZE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(3)** on the remote control to select "V. SIZE".
5. Press the PLAY or STOP button on the remote control until the horizontal over scan is equal to the vertical over scan.

2-13: VERTICAL LINEARITY

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(5)** on the remote control to select "V. LIN".
5. Press the PLAY or STOP button on the remote control until the SHIFT quantity of the OVER SCAN on upside and downside becomes minimum.

2-14: VERTICAL POSITION

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(4)** on the remote control to select "V. POSI".
5. Press the PLAY or STOP button on the remote control until the horizontal line of the monoscope comes to approximate center of the CRT.

2-15: OSD HORIZONTAL

1. Receive monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(5)** on the remote control. The **Fig. 2-2** appears on the display.
4. Press the channel button **(4)** on the remote control to select "OSD H".
5. Press the PLAY or STOP button on the remote control until the difference of A and B becomes minimum. (Refer to Fig. 2-7)





Fig. 2-7

2-16: VERTICAL LINEARITY 60 (AV)

1. Receive the monoscope pattern (Audio Video Input).
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(5)** on the remote control to select "V. LIN".
5. Press the PLAY or STOP button on the remote control until the SHIFT quantity of the OVER SCAN on upside and downside becomes minimum.



ELECTRICAL ADJUSTMENTS

3. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (VCR SECTION)



ELECTRICAL ADJUSTMENTS

(TV SECTION)



CRT PCB

ELECTRICAL ADJUSTMENTS

4. PURITY AND CONVERGENCE ADJUSTMENTS

NOTE

1. Turn the unit on and let it warm up for at least 30 minutes before performing the following adjustments.
2. Place the CRT surface facing east or west to reduce the terrestrial magnetism.
3. Turn ON the unit and demagnetize with a Degauss Coil.

4-1: STATIC CONVERGENCE (ROUGH ADJUSTMENT)

1. Tighten the screw for the magnet. Refer to the adjusted CRT for the position. (**Refer to Fig. 4-1**)
If the deflection yoke and magnet are in one body, untighten the screw for the body.
2. Receive the green raster pattern from the color bar generator.
3. Slide the deflection yoke until it touches the funnel side of the CRT.
4. Adjust center of screen to green, with red and blue on the sides, using the pair of purity magnets.
5. Switch the color bar generator from the green raster pattern to the crosshatch pattern.
6. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
7. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.
8. Adjust the crosshatch pattern to change to white by repeating steps 6 and 7.

4-2: PURITY

NOTE

Adjust after performing adjustments in section 4-1.

1. Receive the green raster pattern from color bar generator.
2. Adjust the pair of purity magnets to center the color on the screen.
Adjust the pair of purity magnets so the color at the ends are equally wide.
3. Move the deflection yoke backward (to neck side) slowly, and stop it at the position when the whole screen is green.
4. Confirm red and blue color.
5. Adjust the slant of the deflection yoke while watching the screen, then tighten the fixing screw.




Fig. 4-1

4-3: STATIC CONVERGENCE

NOTE

Adjust after performing adjustments in section 4-2.

1. Receive the crosshatch pattern from the color bar generator.
2. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
3. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.

4-4: DYNAMIC CONVERGENCE

NOTE

Adjust after performing adjustments in section 4-3.

1. Adjust the differences around the screen by moving the deflection yoke upward/downward and right/left. (**Refer to Fig. 4-2-a**)
2. Insert three wedges between the deflection yoke and CRT funnel to fix the deflection yoke. (**Refer to Fig. 4-2-b**)




Fig. 4-2-a






Fig. 4-2-b


TV BLOCK DIAGRAM




Y/C/AUDIO/HEAD AMP/21PIN/IN/OUT BLOCK DIAGRAM




MICON/POWER/OPERATION/DECK BLOCK DIAGRAM



T' TEXT BLOCK DIAGRAM




PRINTED CIRCUIT BOARDS
MAIN/CRT
SOLDER SIDE




PRINTED CIRCUIT BOARDS


OPERATION SOLDER SIDE




DECK SOLDER SIDE



**PRINTED CIRCUIT BOARDS
SYSCON (INSERTED PARTS)
SOLDER SIDE**




**PRINTED CIRCUIT BOARDS
SYSCON (CHIP MOUNTED PARTS)
SOLDER SIDE**




Y/C/AUDIO/HEAD AMP SCHEMATIC DIAGRAM

(SYSCON PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS
MEASURED WITH THE DIGITAL TESTER
DURING PLAYBACK.



MICON SCHEMATIC DIAGRAM (SYSCON PCB)








POWER SCHEMATIC DIAGRAM (SYSCON PCB)

FROM TV POWER

CD810 (CP810) CH2A015A
1 GND
2 AT+12V
3 AT+12V
4 P.CON+9V
5 AT+5.6V
6 MOTOR_GND
7 AT+30V
8 POWER_FAIL[DC]
9 AT+21V
10 +6V

AT+30V
POWER_FAIL[DC]
AT+5.6V
W812 AT+5.6V



NOTE: THE DC VOLTAGE AT EACH PART WAS
MEASURED WITH THE DIGITAL TESTER
DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE
CRITICAL FOR SAFETY, USE ONES
DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPEREES PAR UN ETANT
DANGEREUSES AU POINT DE VUE SECURITE
N'UTILISER QUE CELLES DÉCRITES
DANS LA NOMENCLATURE DES PIÈCES.

CAUTION: DIGITAL TRANSISTOR




CAUTION: DIGITAL TRANSISTOR




PCB010
VM9155


21PIN/IN/OUT SCHEMATIC DIAGRAM (SYSCON PCB)



CHROMA/IF SCHEMATIC DIAGRAM (SYSCON PCB)



SOUND AMP SCHEMATIC DIAGRAM
(SYSCON PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS
MEASURED WITH THE DIGITAL TESTER
DURING PLAYBACK.

PCB010
VM9155

T'TEXT SCHEMATIC DIAGRAM

(SYSCON PCB)




PCB010
VM9155

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS
MEASURED WITH THE DIGITAL TESTER
DURING PLAYBACK.

TV POWER SCHEMATIC DIAGRAM (MAIN PCB)



DEFLECTION SCHEMATIC DIAGRAM

(MAIN PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED
WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST
WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


ATTENTION: LES PIECES REPEREES PAR UN ETANT
DANGEREUSES AU POINT DE VUE SECURITE
N'UTILISER QUE CELLES DECrites
DANS LA NOMENCLATURE DES PIECES.

CAUTION: SINCE THESE PARTS MARKED BY ARE
CRITICAL FOR SAFETY, USE ONES
DESCRIBED IN PARTS LIST ONLY.

CAUTION: DIGITAL TRANSISTOR



CRT SCHEMATIC DIAGRAM (CRT PCB)




CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARÉES PAR UN ETANT DANGEREUSES EN POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.




OPERATION SCHEMATIC DIAGRAM

(OPERATION PCB)



**DECK SCHEMATIC DIAGRAM
(DECK PCB)**




CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY .

ATTENTION: LES PIECES REPERES PAR UN ETANT DANGEREUSES AU POINT DE VUE SECURITE N'UTILISER QUE CELLES DECrites DANS LA NOMENCLATURE DES PIECES.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE .

INTERCONNECTION DIAGRAM




WAVEFORMS


TV POWER



① 5V 0.1ms/div




⑦ 20V 20μs/div




⑫ PB
10mV 5ms/div


DEFLECTION



③ 0.5V 10ms/div




⑧ 10V 10ms/div




⑬ POWER ON
200mV 50ns/div


TV POWER



④ 200mV 50μs/div




⑨ 20V 10ms/div




⑭ POWER ON
0.5V 10μs/div


CRT



⑤ 2V 20μs/div




⑩ 1V 10μs/div




⑯ POWER ON
2V 20μs/div


Y/C/AUDIO/HEAD AMP



⑥ 20V 20μs/div




⑪ PB
2V 10ms/div




⑯ POWER ON
200mV 10μs/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


WAVEFORMS




(17) POWER ON
50mV 1ms/div




(22) POWER ON
1V 20μs/div




(27) PB
1V 0.5μs/div




(18) POWER ON
1V 1ms/div




(23) POWER ON
2V 20μs/div




(28) PB
0.5V 10μs/div




(19) REC
10V 5μs/div




(24) POWER ON
2V 5ms/div




(29) PB
2V 20μs/div



(20) REC
10V 5μs/div




(25) PB
50mV 10ms/div




(30) PB
1V 50ms/div


MICON



(21) POWER ON
1V 50ns/div




(26) PB
50mV 0.5ms/div




(31) POWER ON
0.5V 10μs/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


WAVEFORMS



③② POWER ON
20mV 1ms/div




③⑦ POWER ON
0.5V 20μs/div




④② POWER ON
200mV 10μs/div


CHROMA/IF




③③ POWER ON
5mV 1ms/div




③⑧ POWER ON
0.5V 10ms/div




④④ POWER ON
0.5V 10μs/div




③④ POWER ON
5mV 1ms/div




③⑨ POWER ON
200mV 50μs/div




④⑤ POWER ON
200mV 1ms/div




③⑤ POWER ON
0.5V 20μs/div




④⑩ POWER ON
2V 50μs/div




④⑥ POWER ON
200mV 1ms/div



③⑥ POWER ON
0.5V 20μs/div






④⑪ POWER ON
200mV 0.1μs/div




④⑦ POWER ON
0.5V 20ns/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


MECHANICAL EXPLODED VIEW



MECHANICAL EXPLODED VIEW




CHASSIS EXPLODED VIEW (TOP VIEW)



CLASS	PART NO.	MARK
GREASE	G-555G	AA
	G-488M	AB
	FL-721	AC
	MG-33	AD
OIL	KYODO OIL SLIDAS No. 150	BA

NOTE: Applying positions AA, AB, AC, AD and BA for the grease or oil are displayed for this section. Check if the correct grease or oil is applied for each position.

CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	PART NO.	MARK
GREASE	G-555G	AA
	G-488M	AB
	FL-721	AC
	MG-33	AD
OIL	KYODO OIL SLIDAS No. 150	BA

NOTE: Applying positions AA, AB, AC, AD and BA for the grease or oil are displayed for this section. Check if the correct grease or oil is applied for each position.

MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION			
101	A54715A720	CABINET,FRONT ASS'Y			
102	701WPJB017	CABINET,FRONT			
103	711WPDA318	PLATE,FRONT			
104	7230006988	SHEET,LED			
105	735WPDA362	BUTTON,FRAME			
106	712WPJA735	FLAP			
107	743WKA0032	SPRING,FLAP			
108	741WUA0002	SPRING,EARTH			
109	722A27A002	SHEET,RATING			
110	---	HEAT SINK			
111	---	HEAT SINK			
112	---	HEAT SINK			
113	---	HEAT SINK			
114	---	HEAT SINK			
115	---	METAL SPACER			
116	---	COATING CLIP			
117	8995034000	CORD CLIP UL CO.			
118	761WPA0164	HOLDER,DECK			
119	771WPA0232	PLATE,JACK			
120	752WSA0192	SHIELD,CASE HEAD AMP ASS'Y			
121	753WSA0118	PLATE,EARTH-SYSCON			
122	752WSA0146	PLATE,DECK SHIELD			
123	890PS70100	PUSH SPACER			
124	761WPA0151	HOLDER,M/PCB			
125	761WPA0165	HOLDER,BACK			
126	702WPBA049	CABINET,BACK			
127	752WSA0147	PLATE,SHIELD BOTTOM			
128	753WSA0120	PLATE,BOTTOM-EARTH			
129	761WPA0166	HOLDER,BUSH			
130	735WPA0288	BUTTON,POWER			
131	752WSA0149	SHIELD,COVER			
132	752WSA0191	SHIELD,CASE			
133	800WFAA005	PVC CUSHION SHEET	12x4		
134	755WNA0010	SHEET,PVC			
201	8110630A04	SCREW,TAP TITE (P)	BRAZIER	3x10	
202	8141J40B84	SCREW,TAP TITE (P)	GW15	4x28	
203	810A130804	SCREW/WASHER (A)		M3x8	
204	810B130A04	SCREW/WASHER (B)		M3x10	
205	810B130804	SCREW/WASHER (B)		M3x8	
206	8109630802	SCREW,TAP TITE (B)	BRAZIER	3x8	
207	8117540B04	SCREW,TAPPING (B0)	TRUSS	4x20	
208	8107230604	SCREW,TAP TITE (S)	BIND	3x6	
209	8110630A24	SCREW,TAP TITE (P)	BRAZIER	3x12	
210	8110330804	SCREW,TAP TITE (P)	FLAT	3x8	
211	8107230804	SCREW,TAP TITE (S)	BIND	3x8	
212	8107226604	SCREW,TAP TITE (S)	BIND	2.6x6	
213	8117140A24	SCREW,TAPPING (B0)	PAN	4x12	
214	8110230604	SCREW,TAP TITE (P)	BIND	3x6	
215	8117540A64	SCREW,TAPPING (B0)	TRUSS	4x16	
216	8110630A22	SCREW,TAP TITE (P)	BRAZIER	3x12	
---	JA4KD200	POLYBAG			
---	J5471501	INSTRUCTION BOOK			
---	J5471502	WARRANTY SHEET			
---	791WHA0023	LAMIFILM BAG			
---	792WHA0228	PACKAGE,TOP			
---	792WHA0229	PACKAGE,BOTTOM			
---	793WCDA741	GIFT BOX			

CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300	A54702A420A	DECK ASS'Y	501	8107126A04	SCREW,TAP TITE(S) PAN
		A54702A420A	502	8107226B04	SCREW,TAP TITE(S) BIND
301	850A500022	AHC ASS'Y	503	8107226604	SCREW,TAP TITE(S) BIND
302	85OP200270	BELT,CAPSTAN	504	8109126604	SCREW,TAP TITE(B) PAN
303	85OP900710	LEVER,REC	505	810A126804	SCREW,WASHER(A)
304	85OP500083	BASE,AC HEAD	506	810B126404	SCREW,WASHER(B)
305	85OP800324	SPRING,AC HEAD	507	8102120604	SCREW,PAN
306	85OA000360	MAIN CHASSIS ASS'Y	508	8102120304	SCREW,PAN
307	85OA200081	CLUTCH ASS'Y X	509	8102130304	SCREW,PAN
308	85OA200073	ARM,IDLER ASS'Y	510	82Q3154C5N	POLYSLIDER WASHER
309	85OP600553	ARM,S-S BRAKE	511	82P266005N	POLYSLIDER WASHER(CUT)
310	850A200076	T REEL ASS'Y	512	82Q264713N	POLYSLIDER WASHER
311	85OA300061	LOADING ARM S ASS'Y	513	82P184505N	POLYSLIDER WASHER(CUT)
312	85OA300062	LOADING ARM T ASS'Y	514	83ETW30000	E-RING
313	85OA400210	GUIDE ROLLER ASS'Y	515	810A123504	SEMS A
314	85OA400188	BASE,INCL S ASS'Y	CP101	069R740018	CONNECTOR PCB SIDE
315	85OA400196	BASE,INCL T(S) ASS'Y	CP102	0694220139	CONNECTOR PCB SIDE
316	85OA400197	P5-3 ARM ASS'Y	D1100	DAK0000170	DEW SENSORCW/AL,PLATE
317	85OA400205	PINCH ROLLER BLOCK	H5001	1523D91034	HEAD (AUDIO CONTROL)
318	85OA400175	TENSION ARM ASS'Y	H5002	1543D02013	HEAD (FULL ERASE)
319	85OA400176	TENSION BAND ASS'Y	△ M101	1596P78001	MOTOR (LOADING)
320	85OA400178	PINCH ROLLER LEVER ASS'Y	△ M2001	1594J98007	CAPSTAN DD UNIT
321	85OA600182	BRAKE T ASS'Y	M2003	1589V11007	MICRO MOTOR
322	85OA600183	CAP BRAKE ARM ASS'Y	PCB550	A4C701B550	DECK PCB ASS'Y
323	85OA900213	LINK ASS'Y	Q101	0000700320	TRANSISTOR,PHOTO
324	85OA900216	LINK LEVER ASS'Y	Q102	0000700320	TRANSISTOR,PHOTO
325	85OP200261	LEVER,CLUTCH	△ UN4001	A54702A500	CYLINDER UNIT ASS'Y
326	85OP200262	RING,CLUTCH			A54702A500
327	85OP200263	GEAR,CLUTCH			
328	85OP200271	REEL,S			
329	85OP200273	STOPPER,REEL S			
330	85OP200274	SPACER,LINK LEVER			
331	85OP300178	GEAR,MAIN LOADING			
332	85OP300179	GEAR,LOADING S			
333	85OP300180	GEAR,LOADING T			
334	85OP300186	HOLDER,LOADING GEAR			
335	85OP400472	ADJUST,TENSION			
336	85OP400492	HOLDER,TENSION			
337	85OP400490	LEVER,TENSION			
338	85OP400475	COVER,P4			
339	85OP600543	GEAR,JOINT			
340	85OP600544	GEAR,MIDDLE			
341	85OP600545	CAM,MAIN			
342	85OP600546	CAM,P5			
343	85OP600565	CAM,PINCH ROLLER			
344	85OP600548	ROD,MAIN			
345	85OP700035	REFLECTOR,LED			
346	85OP800318	SPRING,LOADING GEAR			
347	85OP800319	SPRING,P5			
348	85OP800321	SPRING,BRAKE T			
349	85OP800322	SPRING,TENSION			
350	85OP800323	SPRING,CAP BRAKE			
351	85OP800342	SPRING,LOCKER (S)			
352	85OP800326	SPRING,LINK			
353	85OP800328	SPRING,DAMPER			
354	85OP800330	SPRING,RING			
355	85OP800332	SPRING,S-S BRAKE			
356	85OP900680	OPENER,CASS			
357	85OP900683	CASS SIDE L			
358	85OP900684	CASS SIDE R			
359	85OP900709	TAPE GUIDE L (P,R)			
360	85OP900686	TAPE GUIDE R			
361	85OP900707	COVER,SENSOR L			
362	85OP900688	LEVER,FLAP			
363	85OP900690	CASS HOLDER			
364	85OP900691	LOCKER,L			
365	85OP900692	LOCKER,R			
366	85OP900694	SPRING,PACK			
367	85OP900695	BRACKET,TOP			
368	85OP900696	SPRING,CASS EARTH			
369	85OP600540	DRIVER,WORM			
370	85OP600563	BRACKET,MOTOR			
371	85OP600541	WORM			

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO. PART NO.		DESCRIPTION		REF. NO. PART NO.		DESCRIPTION		
		RESISTORS				DIODES		
△ R412	R635812R2J	R, FUSE	2.2 OHM 1W	D531	D2BT0EG01C	DIODE, RECTIFIER	EG-01C	
△ R447	R65582680J	R, FUSE	68 OHM 1/2W	D532	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R449	R5X2CE682J	R, CEMENT	6.8K OHM 7W	or	D534	D1VT001330	DIODE, SILICON	ISS133T-77
△ R450	R5Y2CE682J	R, CEMENT	6.8K OHM 7W		△ D535	D2BTRM11C0	DIODE, RECTIFIER	RM11C
△ R450	R655812R2J	R, FUSE	2.2 OHM 1W	or	△ D536	D2BTRM11C0	DIODE, RECTIFIER	RM11C
△ R452	R655812R2J	R, FUSE	2.2 OHM 1W		△ D538	D28T21DQN9	DIODE, SCHOTTKY	21DQ09N-TA2B1
△ R452	R655812R2J	R, FUSE	2.2 OHM 1W	or	D601	D1VT001330	DIODE, SILICON	ISS133T-77
△ R452	R655812R2J	R, FUSE	2.2 OHM 1W		D602	D1VT001330	DIODE, SILICON	ISS133T-77
△ R501	R655812R2J	R, CEMENT	2.2 OHM 7W	or	D603	D1VT001330	DIODE, SILICON	ISS133T-77
△ R505	R5X28B683J	R, METAL	68K OHM 3W		D604	D28T11ESN1	DIODE, SILICON	11ES1N-TA1B2
△ R510	R32181R39J	R, METAL OXIDE	0.39 OHM 1W	D605	D97U05R61B	DIODE, ZENER	MTZJ5.6B T-77	
△ R511	R63584681J	R, FUSE	680 OHM 1/4W	D791	002132Q130	LED	SLZ-936C-07-S-T1	
△ R512	R3X101103J	R, METAL	10K OHM 1W	D793	002132Q130	LED	SLZ-936C-07-S-T1	
△ R517	R3X28B100J	R, METAL OXIDE	10 OHM 3W	D794	002132Q130	LED	SLZ-936C-07-S-T1	
△ R538	R0G2X2155J	RC	1.5M OHM 1/2W	D852	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R545	R3X20B2R2J	R, METAL OXIDE	2.2 OHM 3W	D854	D97U06R81B	DIODE, ZENER	MTZJ6.8B T-77	
△ R546	R3X28A151J	R, METAL	150 OHM 2W	D855	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R802	R3X28A103J	R, METAL OXIDE	10K OHM 2W	D856	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R805	R3X28A103J	R, METAL OXIDE	10K OHM 2W	D857	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R810	R3X28A103J	R, METAL OXIDE	10K OHM 2W	D858	D1VT001330	DIODE, SILICON	ISS133T-77	
△ R1005	R615J12R7J	R, FUSE	2.7 OHM 1W	D859	D1VT001330	DIODE, SILICON	ISS133T-77	
		CAPACITORS		D860		DIODES		
C352	E00NU2470M	CE	47 UF 16 V	D861	D1VT001330	DIODE, SILICON	ISS133T-77	
C407	E02L03102M	CE	1000 UF 25V	D1001	D2LXE65800	DIODE, SILICON	1N4005E-6580-G23	
C414	P21503475K	CMP	4.7 UF 250V ECQ-E	D1002	D1VT001330	DIODE, SILICON	ISS133T-77	
C421	E5EZ04102M	CE	1000 UF 35V	or	D1003	0010600060	LED	SID1050CM
	E53Z04102M	CE	1000 UF 35V VZ		D1004	D2LXE65800	DIODE, SILICON	1N4005E-6580-G23
C423	P411F3684J	CMPP	0.68 UF 250V ECWF	D1005	D92T1120B0	DIODE, ZENER	RD12FB-T7	
C424	P414F9392H	CMPP	0.0039UF 1.6KV ECWH	D1006	D28T11E1N1	DIODE, SILICON	11E1N-TA1B2	
C430	C01BBP713K	CC	0.001 UF 2KV BP	D1007	D28T11E1N1	DIODE, SILICON	11E1N-TA1B2	
C431	E62D0C220M	CE	22 UF 200V	D1008	D97U05R11B	DIODE, ZENER	MTZJ5.1B T-77	
C502	C13HB07H3K	CC	0.0022UF 2KV B	D1009	D28T11E1N1	DIODE, SILICON	11E1N-TA1B2	
C503	C13HB07H3K	CC	0.0022UF 2KV B	D1010	D28T11E1N1	DIODE, SILICON	11E1N-TA1B2	
C507	E52C0H101M	CE	100 UF 400V	D1011	D1VT001330	DIODE, SILICON	ISS133T-77	
C515	E62FF3152M	CE	1500 UF 25V	D1012	D1VT001330	DIODE, SILICON	ISS133T-77	
△ C516	P2222B224K	CMP	0.22 UF 250V AC MMCA	D1014	D1VT001330	DIODE, SILICON	ISS133T-77	
C517	C01BBP712K	CC	100 PF 2KV BP	D1015	D1VT001330	DIODE, SILICON	ISS133T-77	
C521	E53VFB101M	CE	100 UF 160V	D1016	D97U06R21C	DIODE, ZENER	MTZJ6.2C T-77	
C525	C01BBP7W2K	CC	820 PF 2KV BP	D1017	D1VT001330	DIODE, SILICON	ISS133T-77	
△ C529	CB3930M13M	CC	0.001 UF 250V	D4001	D97U06R81B	DIODE, ZENER	MTZJ6.8B T-77	
C531	E62FF2102M	CE	1000 UF 16V	D4002	D97U06R81B	DIODE, ZENER	MTZJ6.8B T-77	
△ C538	CB3930MH2K	CC	220 PF 250V	D4003	D1VTB721Q0	DIODE, SCHOTTKY	RB721QT-77	
△ C546	CB3930MH3M	CC	0.0022UF 250V	D4202	D28T11ESN1	DIODE, SILICON	11ES1N-TA1B2	
C547	C01BBP7S2K	CC	560 PF 2KV BP	D4501	D97U01301B	DIODE, ZENER	MTZJ13B T-77	
△ C548	CB3930M13M	CC	0.001 UF 250V	D4502	D97U01301B	DIODE, ZENER	MTZJ13B T-77	
C551	E62FF3152M	CE	1500 UF 25V	D4503	D1VT001330	DIODE, SILICON	ISS133T-77	
C801	C01BBP713K	CC	0.001 UF 2KV BP	D4505	D97U01201B	DIODE, ZENER	MTZJ12B T-77	
C1003	E51XWP104Z	CE	0.1 F 5.5V	D4506	D97U01201B	DIODE, ZENER	MTZJ12B T-77	
		DIODES		D4507		DIODES		
D401	D28T11E1N1	DIODE, SILICON	11E1N-TA1B2	D4508	D97U01201B	DIODE, ZENER	MTZJ12B T-77	
D402	D28T10ELS6	DIODE, RECTIFIER	10EL56TA1B2	D4510	D1VT001330	DIODE, SILICON	ISS133T-77	
△ D411	D28T10ELS6	DIODE, RECTIFIER	10EL56TA1B2	D4511	D1VT001330	DIODE, SILICON	ISS133T-77	
		ICS				ICS		
△ D503	D2BTRM11C0	DIODE, RECTIFIER	RM11C	IC351	I01DP75110	IC	AN7511	
△ D504	D2BTRM11C0	DIODE, RECTIFIER	RM11C	△ IC401	I03SD78400	IC	LA7840	
D505	D28T10ELS6	DIODE, RECTIFIER	10EL56TA1B2	△ IC501	I2BT067070	IC	STR-F6707	
△ D506	D94TA27011	DIODE, ZENER	HZ27-1L TD	△ IC502	I1KA97805A	IC	KIA7805API	
△ D508	D28T21DQN9	DIODE, SCHOTTKY	21DQ09N-TA2B1	△ IC503	I07K9A12T0	IC	BA12T	
△ D509	D2BTRU2AM0	DIODE, SILICON	RU2AM V1	△ IC504	IDJD076100	IC	FA7610CP	
△ D512	D28T21DQN4	DIODE, SCHOTTKY	21DQ04N-TA2B1	△ IC505	I1KA97806A	IC	KIA7806API	
D513	D1VT001330	DIODE, SILICON	1SS133T-77	△ IC506	000210001R	PHOTO COUPLER	ON3171R	
D514	D2BXEU2YX0	DIODE, SILICON	EU2YX-V1	△ IC507	I0GA909RD0	IC	PQ09RD08	
D515	D97U03001B	DIODE, ZENER	MTZJ30B T-77	IC601	I03DE68120	IC	LA76812	
D516	D1VT001330	DIODE, SILICON	1SS133T-77	△ IC602	I0Q0978050	IC	NJM7805FD	
D517	D28TQ04N0	DIODE, SCHOTTKY	11EQS04N-TA1B2	IC851	ICKD001060	IC	ET106	
D518	D28T10ELS6	DIODE, RECTIFIER	10EL56TA1B2	IC852	ICKD003170	IC	ET317	
△ D519	D28T21DQN9	DIODE, SCHOTTKY	21DQ09N-TA2B1	IC853	I55DC4053A	IC	TC74HC4053AP	
△ D520	D28T21DQN9	DIODE, SCHOTTKY	21DQ09N-TA2B1	△ IC1001	I07SQ69550	IC	BA6955N	
△ D521	D2BTRU2AM0	DIODE, SILICON	RU2AM V1	IC1002	IE1J0S31AH	IC	RE5VS31A	
D522	D97U01601B	DIODE, ZENER	MTZJ16B T-77	IC1003	I03FE772V0	IC	LC74772V	
D523	D1VT001330	DIODE, SILICON	1SS133T-77	IC1006	I54F50076A	IC	OEC0076A	
D524	D28021DQN4	DIODE, SCHOTTKY	21DQ04N	IC1099	A54715A015	IC	S-24C08ADPA-01	
D525	D17T002440	DIODE, SILICON	1SS244T-77	IC4001	I04F38217F	IC	HA118217F	
		TRANSISTORS				TRANSISTORS		
D526	D1VT001330	DIODE, SILICON	1SS133T-77	Q401	TPYTB03001	COMPOUND TRANSISTOR	DTA114ESTP	
D527	D1VT001330	DIODE, SILICON	1SS133T-77	Q402	TF6FR2AM80	THYRISTOR	CR2AM-8-F8	
D528	D97U05R61B	DIODE, ZENER	MTZJ5.6B T-77	Q403	TC5T018154	TRANSISTOR, SILICON	2SC1815Y(TPE2)	
D529	D1VT001330	DIODE, SILICON	1SS133T-77					

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
MISCELLANEOUS			
CD504	121B164102	CORD, CAR BATTERY	SI-PC107-69
CD601	06CH01010A	CORD, CONNECTOR	CH01010A
CD757	06CH2A014A	CORD, CONNECTOR	CH2A014A
CD801	127C100008	BRAIDED WIRE	TD-07018-9
CD802	06CH01011A	CORD, CONNECTOR	CH01011A
CD803	122U042705	CORD, JUMPER	2-042705
CD810	06CH2A015A	CORD, CONNECTOR	CH2A015A
CD820	06CH2B029A	CORD, CONNECTOR	CH2B029A
CD850	06CH25080A	CORD, CONNECTOR	CH25080A
CF601	1022T38R9A	FILTER, SAW	SAF38.9MAZZ220Z
CF602	1012T04001	FILTER, CERAMIC TRAP	MKT40.4MA110P-TF
CP302	069X120249	CONNECTOR PCB SIDE	B2B-EH-A
CP351	069E270129	CONNECTOR PCB SIDE	8283_0712_00_000
CP401	069W440019	CONNECTOR PCB SIDE	TV-50P-04-A1
CP403	069W420029	CONNECTOR PCB SIDE	TV-50P-02-A1
CP404	069W01001A	CONNECTOR PCB SIDE	003P-2100
CP501	069W320018	CONNECTOR PCB SIDE	TS-80P-02-V1
CP502	0697320039	CORD, UX CONNECTOR	THL-P03P-B1
CP601	069W01001A	CONNECTOR PCB SIDE	003P-2100
CP603	069E290129	CONNECTOR PCB SIDE	8283_0912_00_000
CP757	069E2A0129	CONNECTOR PCB SIDE	8283_1012_00_000 or 1-173981-0
CP801	069W330018	CONNECTOR PCB SIDE	TS-80P-03-V1
CP810	069E2A0129	CONNECTOR PCB SIDE	8283_1012_00_000 or 1-173981-0
CP820	069E2B0129	CONNECTOR PCB SIDE	8283_1112_00_000 or 1-173981-1
CP850	069E250129	CONNECTOR PCB SIDE	8283_0512_00_000
CD1002	06CH22076A	CORD, CONNECTOR	CH22076A
CD1005	122F051702	CORD, JUMPER	2F051702
CD1006	122L040904	CORD, JUMPER	2L040904
CD4005	122L061501	CORD, JUMPER	2L061501
CP1001	069R220021	CONNECTOR PCB SIDE	52287-0211
CP1004	0697280590	CONNECTOR PCB SIDE	TMC-J08P-B1
CP1005	069R750028	CONNECTOR PCB SIDE	52045-0545
CP1006	069R740028	CONNECTOR PCB SIDE	52045-0445
CP4001	0697240600	CONNECTOR PCB SIDE	TOC-C04X-B1
CP4004	0697120320	CONNECTOR PCB SIDE	TMC-T02X-E1
CP4005	069R760028	CONNECTOR PCB SIDE	52045-0645
CP803A	067R104019	WIRE HOLDER	51052-0400
CP803B	067R104019	WIRE HOLDER	51052-0400
CUS011	800WFAA006	CUSHION A	
CUS011	800WFAA006	CUSHION A	
CUS012	800WF00019	CUSHION-C	
CUS013	800WFAA006	CUSHION A	
DY801	027S051005	DY	MDC-66A1076-1
△ F501	0808T04002	FUSE	218004
△ F502	0808T2R502	FUSE	21802.5
△ FB401	043210011F	TRANSFORMER, FLYBACK	3210011F
FH501	06710T0006	HOLDER, FUSE	EYF-52BC
FH502	06710T0006	HOLDER, FUSE	EYF-52BC
FH503	06710T0006	HOLDER, FUSE	EYF-52BC
FH504	06710T0006	HOLDER, FUSE	EYF-52BC
△ ICP501	083PC07002	MICRO FUSE	251007
△ ICP502	083PC07002	MICRO FUSE	251007
△ ICP503	083PC05002	MICRO FUSE	251005
△ ICP504	083PC05002	MICRO FUSE	251005
△ ICP505	083PC04002	MICRO FUSE	251004
△ ICP506	083PC05002	MICRO FUSE	251005
K001	129N000001	WEDGE	VB25SR
K002	129N000001	WEDGE	VB25SR
K003	129N000001	WEDGE	VB25SR
MG801	026B051404	MAGNET CONVERGENCE	JH-225
OS753	077Q000017	REMOTE RECEIVER	PIC-28143TH5
△ RY503	0560V50118	RELAY	ALKS329
SP351	070C132014	SPEAKER	811-08-194
TM101	07660CH390	TRANSMITTER	SBJU00061A
△ TU601	0145511021	TUNER, VHF-UHF	TUWOF4EG-771F2
△ V801	092F090403	COLOR PICTURE TUBE W/O	A23KQT22X(D)
X601	100CT4R406	CRYSTAL HC-94/U	4.433619MHz
X851	100CT01302	CRYSTAL HC-49/U-S	13875KHz
X1001	100CT01002	CRYSTAL HC-49/U-S	10MHz
X1002	100DA32R01	CRYSTAL DT-26	32.768KHz
			or
X4001	100CT4R407	CRYSTAL DSVT-200	32.768KHz
			4.433619MHz

RESISTOR	
RC.....	CARBON RESISTOR
CAPACITORS	
CC.....	CERAMIC CAPACITOR
CE.....	ALUMI ELECTROLYTIC CAPACITOR
CP.....	POLYESTER CAPACITOR
CPP.....	POLYPROPYLENE CAPACITOR
CPL.....	PLASTIC CAPACITOR
CMP.....	METAL POLYESTER CAPACITOR
CMPL.....	METAL PLASTIC CAPACITOR
CMPP.....	METAL POLYPROPYLENE CAPACITOR

SPEC.NO.	M547-15A
O/R NO.	W065513