

Emergency charger

Emergency charger allows for the recharge of phone batteries, readers or other devices with the connectors supplied even when there is not an outlet

Plugging into a phone, MP3 player, GPS or other devices with low battery, allows you the immediate use of the equipment providing the energy needed for its operation

Works with 2 AA batteries which is alkaline rechargeable Ni-Cd or Ni-Mh

Replenishment of equipment that is connected may be partial and vary depending on the characteristics of AA batteries used and the capacity of the battery to recharge

Alkaline or rechargeable batteries can be used one or more times depending on the characteristics of the battery and the device previously loaded

Equipped with a USB output and 6 interchangeable connectors that are compatible with many models of mobile phones and devices with mini USB jack

Check the compatibility of your devices with the connectors supplied before the purchase of this product

How to use:

1. Open the charger pulling the ends outward
2. Insert the AA batteries observing the polarity
3. Connect the cable to the USB charger
4. Use the connector cable for some of Nokia phones or insert the connector compatible with your models
5. The green indicator light informs that charging is in process

Remove the AA batteries at the end of charging and when not in use for long periods!

Keep away from heat and water!

Keep out of reach of children!

Do not open it and do not try to repair it yourself!

Do not use it to recharge non-rechargeable batteries!

Technical characteristics

input 2,0Vdc - 3,2Vdc (2xAA batteries)

output 4,2Vdc - 5,6Vdc – 300mA